

## ST73-31.10

**Temperature controller** 

**Order number 900206.003** Old Id.Nr.: 145250



230V-1 2 3 4 K1/ 16(2,2)A 250V-6 5 F1 PTC


## Wiring diagram

## **Product description**

The controller ST73-31.10 was developed for simple thermostatic applications. The round housing allows applications at locations in which formerly only mechanical controls were in use. The unit is supplied with 230V AC. The installed relay has a maximum electric Ohm load of 16A. Inductive loads can be switched up to 2.2A. An additional buzzer can be activated.

Sensor: PTC Range: -50...140°C Front size: 72mm x 72mm Panel cut-out: 60.5mm round Tightness: front IP65 Connector: flat plug 6.3mm

ST 73 ...





## **SOFTWARE**.10

### **Description**



#### UP key

By pressing this key the parameter or parameter value is increased.



#### **DOWN** key

By pressing this key the parameter or parameter value is increased. The alarm buzzer can be cancelled by this key.



#### SET key

The display normally shows the actual value. When the SET key is pressed, the display changes to show the control setpoint.

#### First control level:

#### Adjusting the setpoint

Pressing the SET key, the setpoint S1 shows on the display.

If the setpoint is to be changed, the SET key is to be kept pressed while adjusting the setpoint with the keys UP and DOWN

Para- meter	Function	Adjustable Range	Standard setting	Customer setting
S1	Setpoint	P4P5	0.0°C	



#### Second control level (P-Parameters):

#### Adjusting the control parameters

Simultaneously pressing the UP and DOWN key for at least 4 seconds opens a parameter list containing control parameters.

With the UP and DOWN keys the list can be scrolled in both directions.

Pressing the SET key will give you the value of the respective parameter. Pressing also the UP or DOWN key at the same time the value can be adjusted. Release the UP or DOWN button before releasing the SET button and the new value is saved into the non-volatile memory.

Return to the initial position takes place automatically, if no key is pressed for 60 seconds, or by simultaneously pressing the UP and DOWN key for approx. 4 seconds

Para-	Functions	Adjustable range	Standard	Customer
meter			Setting	setting
P0	Display of actual value			
P2	Hysteresis K1	0.5 99.9 °K	1.0 °K	
P4	Control range limitation – minimum setpoint	-99P5	-99 °C	
P5	Control range limitation – maximum setpoint	P4999 °C	999 °C	
P6	Actual Value Correction	-20.0 +20.0 °K	0.0 °K	
P19	Keyboard lock	0: not locked 1: locked	0	
P30	Lower alarm value	-99999 °C	-99 °C	
P31	Upper alarm value	-99999 °C	999 °C	
P32	Hysteresis alarm circuit (one-sided)	0.5 99.9 °K	1.0 °K	
d0	Defrosting interval	199 hours 0: no defrosting	0	
d2	Defrosting temperature	-99.0999.0 °C	10.0 °C	
d3	Defrosting time limit	199 min 0: without time limit	30 min	



#### Parameter description second control level

#### P0: Actual value

The here indicated temperature presents the actual measured value. If the control setpoint is indicated by the help of parameter A32, the actual value can only be seen with this parameter.

#### P2: Hysteresis contact K1

The hysteresis can be set symmetrically or one-sided at the setpoint (see A40). At one-sided setting, the hysteresis works downward with heating contact and upward with cooling contact (see fig. 1 - 2).






Fig. 1: Heating controller, one-sided hysteresis





## P4: Control range limitation – minimum setpoint

#### P5: Control range limitation – maximum setpoint

The adjustment range of the setpoint can be limited in both directions. This is to prevent the end user of a unit from setting inadmissible or dangerous setpoints.

#### P6: Actual value correction

This parameter allows the correction of actual value deviations caused for example by sensor tolerances or extremely long sensor lines. The regulation measure value is increased or decreased by the here adjusted value.

#### P19: Key-lock

The key-lock allows blocking of the control keys. In locked condition parameter adjustments with keys is not possible. At the attempt to adjust the parameters despite key-lock the message "===" appears in the display.

#### P30: Lower alarm value

#### P31: Upper alarm value

The exit alarm is a boundary alarm or a range alarm with symmetrical hysteresis (see parameter P32). Both at the boundary alarm and the range alarm, limit values can be relative, i.e. going along with the setpoint, or absolute, i.e. independent of the setpoint. At boundary alarm the hysteresis works one-sided inwardly, and at range alarm outwardly.



Boundary alarm function (see fig. 3): The alarm contact is closed if the process temperature is above the upper or below the lower boundary value.




Fig. 3: Boundary alarm, rel. boundaries

Range alarm function (see fig. 4):

Opposite switching behaviour to the boundary value alarm. The alarm contact is closed if the actual value remains between the boundary values.




Fig. 4: Range alarm, abs. boundaries

## P32: Hysteresis alarm circuit

Hysteresis is set one-sided at the adjusted limit value. It becomes effective depending on alarm definition.

## d0: Defrosting interval

The "defrosting interval" defines the time, after which a defrosting process is started. After each defrosting start, this time is reset and runs the next interval.

## d2: Defrosting temperature limit

This permits to terminate defrosting when the adjusted desired temperature value is reached. The defrosting time set with "d3" nevertheless runs at the same time, i.e. it functions as safety net to terminate the defrosting process in case the defrosting temperature is not reached.

## d3: Defrosting time limit

After the here set time the defrosting process is terminated.



#### Third control level (A-level)

Access to the third control level is granted when selecting the last P-parameter on the second control level. Continue to press the UP key for approximately 10 seconds until "PA" appears. Continue to press the UP key and additionally press the DOWN key for about 4 seconds and the first A-parameter of the third control level is indicated.

With the keys UP and DOWN you can scroll the list in both directions. Pressing the SET key will give you the value of the respective parameter. By pressing the UP or DOWN key at the same time the value can be adjusted.

Return to the initial position takes place automatically, if no key is pressed for 60 seconds, or by simultaneously pressing the UP and DOWN key for approx. 4 seconds.

Para-	Functions	Adjustable Range	Standard
meter			Setting
A1	Switch mode K1	0: heating contact	Pt100: 0
		1: cooling contact	PTC: 1
		2: function alarm K1	
		3: function alarm K1 inverted	
A3	Function of contact K1 at	0: relay off	0
	sensor error	1: relay on	
A8	Display mode	0: integrals	
	(all parameter indications are	1: decimals in 0.5°C	1
	presented in 0,1°K)	2: decimals in 0.1°C	
A19	Parameter lock	0: no lock	0
		1: A-parameter locked	
		2: A- and P-parameter locked	
A30	Function alarm exit	0: boundary alarm, relative	0
,		1: boundary alarm, absolute	ľ
		2: range alarm, relative	
		3: range alarm, absolute	
A31	Other alarm functions	0: without function	0
AJI		1: display flashing	0
		2: buzzer active	
100		3: display flashes and buzzer active	
A32	Setpoint display	0: display shows actual value	
		1: display shows setpoint S1 (S1')	
A40	Hysteresis mode contact K1	0: symmetrically	
		1: one-sided	1
A50	Minimum action time contact K1 "On"	0999 sec.	0 sec.
A51	Minimum action time contact K1	0999 sec.	0 sec.
	"Off"		
A54	Time delay relay K1	0999 sec.	0 sec.
	after mains ON		
A56	Alarm suppression	060 min	20 min.
	after mains ON		
A60	Sensor type	11: PT100 2-wire	Dependent
		21: KTY81-121 2-wire	on hardware
		22: PT1000 2-wire	
A70	Software filter	1: inactive	
		average value with:	
		1128: 1128 measuring values	
A80	Temperature scale	0: Fahrenheit	1
700		1: Celsius	1
Dro	Drogram varaion		
Pro	Program version	-	-



#### Parameter description third control level

#### The following values can change the equipment characteristics and are therefore to be set with utmost care:

#### A1: Switch mode contact K1

The switch mode for the relay, i.e. cooling or heating function, can be programmed independently at works. Heating function means that the contact opens as soon as the setpoint is reached, thus power interruption. At cooling function the contact closes, if the actual value is above the required setpoint.

#### A3: Function of contact K1 at sensor error

At sensor error the selected relay falls back into the condition pre-set here.

#### A8: Display mode

The value can be indicated in integrals or with decimals in 0,5°K or 0,1°K. At indication in 0,5°K the value is rounded up or down. In general, all parameter indications are presented in 0,1°K.

#### A19: Parameter lock

This parameter enables locking of each parameter level. If third level is locked, only parameter A19 may be changed.

#### A30: Function alarm exit

The alarm exit evaluates an upper and a lower limit value (see parameters P30 and P31), whereas a selection is possible as to whether the alarm is active if the temperature lies within these two limits, or whether the alarm is released if the temperature lies beyond them. In the case of sensor error, the alarm is activated independently of this adjustment. The exit can also be inverted with parameter A1, so that it functions like a release

#### A31: Other alarm functions

Here can be selected whether, in the case of an alarm, the indication to flash and/or the buzzer is to start. Sensor alarm (display F1L or F1H) is indicated independently thereof by flashing display and the buzzer.

#### A32: Setpoint display

A32=0 indicates the actual value, A32=1 statically indicates the setpoint in the display. Therefore, the current actual value can only be indicated with parameter P0.

#### A40: Hysteresis mode contact K1

These parameter allows selection as to whether the hysteresis value which is adjustable with P32, is set symmetrically or one-sided at the respective switching point. At symmetrical hysteresis, half of the hysteresis' value is effective below and half of the value above the switching point. The one-sided hysteresis works downward with heating contact and upward with cooling contact.

#### A50: Minimum action time contact K1 "On"

#### A51: Minimum action time contact K1 "Off"

These parameters permit a delay in switching on/off the relay in order to reduce the switching frequency. The adjusted time sets the entire minimum time period for a switching-on or switching-off phase.

#### A54: Delay after "Power-on"

This parameter allows a switching-on delay of relays after switching-on the mains voltage. This delay corresponds with the time set here.



#### A56: Alarm suppression after "Power-On"

This parameter allows a switching-on delay of the alarm contact after switching on the mains voltage or setpoint change-over. This delay corresponds with the time set here.

#### A60: Sensor type

These parameter permits selection of the sensor type, if the needed hardware prerequisites are available.

#### A70: Software filter

With several measuring values, it is possible to obtain an average value. This parameter can determine by how many measured values an average value is to be formed. If a sensor with a very fast reaction to external influences is used, an average value ensures a calm signal process.

#### A80: Temperature scale

Indication can be switched between Fahrenheit and Celsius. At conversion, the parameters and setpoints maintain their numerical value and adjustment range. (Example: A controller with the desired value of 0°C is switched to Fahrenheit. The new desired value is then interpreted as 0°F, which corresponds to a temperature of -18°C).

NOTE: Indication limits with °F can be smaller than the actual measuring range!

#### Error codes

Display	error	What to do
F1L	sensor short circuit	new sensor
F1H	sensor failure	new sensor
F3L	Boundary alarm	Temperature low
F3H	Boundary alarm	Temperature high
F3	Range alarm	Temperature in between boundaries
	Keyboard lock active	see Parameter P19 or A19
display flashing,	Temperature alarm	cancel buzzer
buzzer	(see A31)	with $ abla$ button
EP	lost of data in EE-Prom	repair of controller



## Technical data of ST73-31.10

#### **Measuring input**

F1: Resistance thermometer PTC KTY 81-121 Measuring range: -50...150°C Measuring accuracy: +/- 1K or +/- 0.5% of measuring range

#### **Outputs**

**K1:** Relay 16(2,2)A 250V~, normally-open contact Additional buzzer, 85dB

#### Display

One 3-digit LED Display, height 13 mm, colour red

#### **Power supply**

230V, 50Hz / 60Hz, power consumption max. 20mA

#### Connectors

Pins 1 to 4:	flat plug 6.3 x 0.8 mm
Pins 5 and 6:	flat plug 2.8 x 0.5 mm

#### **Ambient conditions:**

Storage temperature:	-20+70°C
Operating temperature:	0+55°C
Relative humidity:	max. 75% without dew

#### Weight

ca. 200g

# Enclosure

Front IP65

### Installation data

Front size: Panel cut-out: Installation depth: Mounting: square, 72 mm x 72 mm round, diameter 60.5 mm ca. 65 mm with connector with fixing strap