



Push for 5 seconds to changing the setting of the contact of the safety thermostat.

Make attention: after 5 second on the set point display will appear:
NC for thermostat contact normal close.

NA for thermostat contact normal Open.

Push untill the setting change Position.