

- 230V-50Hz-1~ (line+neutral) to be connected to 1st and 4th (first and last) position of connector
- Earth pin (green-yellow) is in 2nd position, next to the black one
- Brown cable in 3rd position is internally tied to the brown cable which goes to the capacitor, for the correct working of the pump this pin is not to be connected

- 230V-50Hz-1 ~ (Leitung + Neutralleiter) zum Anschließen an die erste und vierte (erste und letzte) Position des Steckers
- Der Erdungstift (grün-gelb) befindet sich in der zweiten Position neben der schwarzen
- Das braune Kabel in der 3. Position ist intern mit dem braunen Kabel verbunden, das zum Kondensator führt. Für den korrekten Betrieb der Pumpe darf dieser Pin nicht angeschlossen werden