



# WAREWASHING SPECIAL RINSE AID

## HYLINE HLD-5000



## HYLINE HLD-5000

### CUSTOMER BENEFIT

- Liquid rinse aid fo use with demineralized water
- Suitable in combination with osmosis or demineralization
- Highly concentrated
- Gentle on decor
- Outstanding drip-off properties
- Stain-free drying

### DOSING/APPLICATION

0.1 to 0.4 g/l depending on material type of the washware and water quality.

Only use the special rinse aid HLD-5000 with demineralized water with a conductance of  $<100\mu\text{S}$ . Demineralized water can be provided through a demineralization or reverse osmosis system.

- Designed for commercial use only
- Not suitable for manual dosing
- Adhere to dosage instructions

### COMPOSITION/INGREDIENTS

Non-ionic tensides

### PRODUCT SAFETY AND STORAGE INSTRUCTIONS

For hazard warnings and safety instructions, refer to the material safety data sheet.

Always store in original container. Protect against frost and heat. Protect against direct sunlight.

### APPLICATIONS

- Designed for commercial glasswashers
- Only suitable for demineralized water with a conductance of  $<100\mu\text{S}$
- Suitable for all kinds of drinking glasses and glass types with decor
- Guarantees relaxation of the rinse water and therefore a quick and spotless drying of the glasses

### TECHNICAL DATA

Colour	Colourless liquid
pH-value	5 (concentrated)
Specific weight	1.0 kg/l
Shelf life	12 months
Storage	In upright container, protected against frost, between 2 - 25°C

### AVAILABLE CONTAINERS

ITEM NO.	SALES UNIT	CONTAINER
HLD-5000	10 litres	Canister

### NOTES

When changing detergent or rinse aid, observe the instructions in the user manual.

For more information on the HOBART HYLINE range, other HOBART products and material safety data sheets, please visit [www.hobart-export.com](http://www.hobart-export.com).