


Einbauanleitung CleanJet Pumpenset 8720.1526

Installation instruction CleanJet Pump 8720.1526



Der Satz besteht aus:

A	Pumpe	3002:1009
B	Gerade-Einschraubstück	2062.0351
C	Winkel-Einschraubstück	2062.0339

The set consists of:

A	Pump	3002:1009
B	Straight screw joint	2062.0351
C	Elbow screw joint	2062.0339

Zum Einbau:

Auf Grund der unterschiedlichen Gerätegrößen und Modelle wird jeder Pumpe die oben angeführten Teile beigelegt. Passendes Einschraubstück auswählen und Gewinde mit Teflonband (Bestellnummer 5012.0524 nicht im Lieferumfang enthalten) gegen die Einschraubrichtung umwickeln (ca. 10 Lagen).

Achtung: Teflonband darf die Öffnung des ausgewählten Einschraubstückes nicht blockieren.

Einschraubstück in die Pumpe einschrauben (Bild 2). Nach Einbau der Pumpe auf Dichtheit überprüfen.

For installation:

Due to the different unit sizes and models every pump is shipped with the above mentioned parts.

Choose suitable screw joint and wrap teflon tape around the thread (part number 5012.0524 not included in the kit). As it is a right handed thread, wrap the tape left handed over the thread (approx. 10 layers).

Attention: Make sure that the teflon tape does not block the opening of the screw joint.

Screw the joint into the pump (pic. 2). After the installation of the pump check the system for tightness.

